



INSTALLATION MANUAL

Insert colour coded wires into the appropriate colour coded section of the FishVue LIME connector.

NOTE: To install wire into FishVue LIME Unit - lift the orange clip of the connector, insert the wire, and close orange clip. Strip back the insulation of all connection wires 1/2" before insertion.*See Below*



Stripped Back Wire Insulation

